



Part Number	Description	Quantity Available
0059-0008-3	CHECK VALVE	2
009519-05	SWITCH, AIRFLOW SENSOR	2
009519-06	SWITCH, AIR FLOW SENSOR	1
009519-08	SWITCH, AIR FLOW	1
0108084-05	SYSTEM PILOT RESTRAINT	5
0108084-101	SYSTEM PILOT RESTRAINT	1
016498-03	LOW FLOW SENSOR	3
055046B	ACTUATOR LOCKUP	1
071-50015-0100	SAT COM UNIT	1
08-60163-002	HYDRAULIC ACCUMULATOR	3
08-60164-002	ACCUMULATOR HYD	1
0861HB	SENSOR ANGLE OF ATTACK	2
0871BN8-1	DETECTOR ICE	1
1000-201	ZONAL DRYER	1
10275B03C02	MODULE, CABIN PRESSURE ACQU	1
103770-8	VALVE PRIMARY OUTFLOW	3
1081100-3	ACTUATOR DOOR NLG	3
1-09750-00-00	DUCT-APU EXHAUST	1
11-0049	BATTERY CHARGER	2
1104SD100-301	SHAFT FLEX DRIVE INBD/OUTBD	3
1110-5AD	SEAT ASSY, PILOT	1
1110-7AD	SEAT ASSY, CO PILOT	1
11-254-8	SWITCH, PRESSURE SELECTOR	2
1151336-1	CONTROLLER ANTI ICE TEMP	6
122113-02AA	SECTION ASSY, AISLE STD	2
123905-23CA	DRESS COVER BACK	1
126758-7	UNIT POWER DRIVE	1
128646-5-1	PRESS SPEED SWITCH	2
128646-6	SWITCH	2
130158-1-1	CHECK VALVE	1
1327-82	ANTENNA ELT	1
14239-103	DUCT, BLEED AIR	1
14350-007	TANK ASSY	1
14411-110	DUCT ASSY	2
14431-103	COUPLER, ANTI-ICE	1
14432-106	TUBE ASSY, PICCOLO	1
14463-108	TUBE ASSY, PICCOLO	3
14463-109	PICCOLO TUBES LEFT HAND OUTB'D	4
14463-110	TUBE PICCOLO	5
14464-105	DUCT ASSY ANTI-ICING SYSTEM (LH).	1
14464-106	DUCT ASSY - RH WING	2
14466-105	COUPLING, SLIDER	1
1500-1100-500	HGS DRIVE ELECTRONICS UNIT	1
1500-1470-502	PANEL CONTROL HGS	3



Part Number	Description	Quantity Available
1500-2230-001	COMBINER HGS	2
15A101-101	EXHAUST DUCT APU	1
15A106-102	BLANKET UPPER HALF	1
15A106-103	BLANKET LOWER HALF	1
16124-101	NOSE GEAR AXLE	23
16210-101	STEERING PLATE ASSY	10
16300-106	ACTUATOR	1
16400-105	BRACE DRAG NLG	5
16403-1	PIN,DRAG TRUNNION	6
16404-1	PIN, DRAG APEX	6
16414-103	DRAG BRACE, UPPER	1
16424-101	DRAG BRACE, LOWER	5
16480-101	STEERING MANIFOLD ASSY	1
16520-101	ACTUATOR RETRACT NLG	5
16528-1	PISTON	1
1659-1	CONTROLLER TEMP WINDSHIELD	4
16600-103	NLG UPLOCK ASSY	3
16650-101	MODULE CONTROL STEERING	20
16735-109	RVDT FEEDBACK	5
16736-105	STEERING SERVO VALVE	2
16740-105	RVDT, RUDDER	15
16745-101	SWITCH, STEERING PRESSURE	12
16789-101	COMPENSATOR UNIT HYD	13
16850-101	SOLENOID VALVE	12
16900-107	UNIT, CONTROL, STEER WIRE	9
1697M50G01	HARNESS ASSY	1
1697M51G02	CABLE HARNESS	4
17002-115	MLG ASSY L/H	1
17008-115	ACTUATOR MLG SIDESTAY	12
17027-7	CYLINDER, PAINTED	2
17028-3	ROD END ASSY	5
17040-1	PINTLE PIN	17
17041-1	PIVOT PIN	3
17041-3	PIVOT PIN	2
17050-101	AXLE S/A	8
17051-101	UPLOCK ASSY MLG	6
17064-108	MAIN FITTING	1
17074-111	LOWER-INNER PIPE	1
17074-112	PIPE S/A	1
17076-1	PIN SIDE STAY	3
17084-103	TRAILING ARM	1
17100-105	SHOCK STRUT MLG R/H	1
17105-105	CYLINDER, MLG PAINTED	4
17115-101	PISTON ASSY, MLG	8



Part Number	Description	Quantity Available
17300-143	HARNESS	3
17300-153	HARNESS	1
17300-203	STEERING HARNESS	2
17300-205	HARNESS, WOW SENS	2
17300-221	L/H HARNESS ASSY - NLG SENSOR /WOW #1	3
17311-109	SWIVEL ASSY	1
17314-112	PIPE SUBASSY UPPER INNER MLG (RH)	1
17319-105	ACTUATOR, AUXILIARY DOWNLOCK	16
176965-31	BOTTLE PORTABLE OXYGEN	3
1B5-11	PUMP ASSY	3
20-035008-067	UNIT CONTROL BLEED AIR	3
2013-1A	EMERG. LIGHT POWER PACK	1
206001-003	ACCOUSTIC FILTER	2
2118800-2	CONTROL UNIT, APU	3
211C223-404A	SWITCH, PRESSURE	2
211C223-461A	SWITCH PRESSURE	3
21SN41-111	PRESSURE SWITCH	7
21SN41-112	PRESSURE SWITCH	4
21SN41-113A	APU BOOST PUMP SWITCH	5
226114-2	PUMP, FUEL	1
228-50020-801	INLET COWL	1
228-50100-803	AFT FLANGE	1
228-50102-809	PANEL ASSY	3
228-50218-801	BLOCKER DOOR	4
228-50219-802	ASSY, LOWER INBD R/H	3
228-50219-804	DOOR ASSY, LOWER, INBD BLOCKER (RH)	3
228-50253-104	FAIRING	2
228-50253-807	FAIRING	2
228-50281-801	SUPPORT, CF34 T/R MAIN TRACK	4
228-50291-103	FAIRING	3
228-50854-105	CASCADE - PYLON LOWER (LH)	1
228-50854-802	CASCADE - PYLON LOWER (RH)	2
228-50860-105	CASCADE - UPPER CENTRE (LH)	1
228-50860-801	CASCADE UPPER CENTER	3
228-50862-109	CASCADE - PYLON UPPER (LH)	2
228-50862-802	CASCADE - PYLON UPPER (RH)	2
228-55030-113	JETPIPE TAIL CONE	1
228-56330-105	DUCT ASSY	1
2313M/340-2	WIPER MOTOR CONVERTER	1
2313M-341-2	WINDSHIELD WIPER MOTOR	2
2314M229-4	WIPER ASSY RIGHT HAND	1
2314M-449-1	WIPER ARM ASSY	3
2314M450-1	WIPER ASSY	2
2314M-450-1	WIPER ARM ASSY	1



Part Number	Description	Quantity Available
237BC101-1	BATTERY CHARGER	1
2-459-06	DIMMER LIGHT ASSY	3
2530-1	VALVE PRESSURE RELIEF	10
25415011A	SNUBBER ASSY	1
27000-3	CNTL UNIT FLT SPOILER	1
27000-7	POWER CTRL UNIT SPOILER	2
27200-7	ACTUATOR AILERON	2
27400-1	RUDDER PCU	5
27600-3	ELEVATOR PCU	4
2770082-101	REF/DEF ADAPTER	1
2770086-103	FUEL DRAIN VALVE	1
27800-3	ACTUATOR SPOILER GROUND	5
2831-45	HEATER BLOWER ASSY	1
2880022-101	VALVE FUEL PRESS RELIEF	3
2880022-102	PRESSURE RELIEF VALVE	1
2890056-102	APU NEG 'G' RELIEF VALVE	3
2890077-101	SCAVENGE-EJECTOR PUMP	1
2890078-101	EJECTOR PUMP	1
28VS100Y-10B	TRU, CONVERTER-FAN COOLED	1
28VS100Y-10C	CONVERTER, STATIC	3
2920030-103	VALVE CHECK	1
2920041-103	FUEL SWING CHECK VALVE	1
2950001-101	VALVE APU NEG 'G' RELIEF VLV	1
2977-01	CUFF HEATER, PUMP	9
2977-05	VALVE ASSY	1
2LA006178-02	STROBE WING LIGHT	5
2LA006636-11	PSU	3
2LA006636-12	PSU ASSY	2
2LA006636-21	PASSENGER SERVICE UNIT	3
2LA006636-22	PSU ASSY	7
2LA006636-41	PANEL ASSY, PSU (LH)	2
2LA006636-42	PANEL ASSY, PSU (RH)	2
2LA006746-21	SIGN ASSY /LH	1
2LA006746-22	PANEL CONTROL	2
2LA006746-41	PSU LIGHT PANEL	1
2LA006746-42	PSU LIGHT PANEL	1
2NSN41-112	PRESSURE SWITCH	1
30000-09	PITCH FEEL CTRL UNIT	1
30027-0000-02	CONTROL OIL SYSTEM	1
303-0001-01	VENT ASSY - PRESSURE RELIEF	3
3044T23P01	PLUG, BOROSCOPE	1
304546-6	HARNESS	1
3214442-4	VALVE REGULATOR	7
3215622-2	VALVE DUAL PRESSURE	4



Part Number	Description	Quantity Available
3272570-6	ACTUATOR ASSY BALLSCREW	2
3289590-2	VALVE BLEED 14TH STAGE R/H	6
34600037-1	FIRE BOTTLE CARGO	3
35610-2-310	ELEMENT - HEAT SENSING	1
35A557	STALL WARNING SHAKER	3
3610004-5	NOZZLE ASSY, GTCP36 PRIMARY FUEL	5
3610004-6	NOZZLE ASSY, GTCP36 SECONDARY FUEL	6
377-02836	CONTROL DETECTOR FIRE	4
3830156-2	MANIFOLD	2
3830166-2	VALVE ASSY, FLOW DIVIDER	2
3881017-1	CONTAINER FILTER	1
39-771	VALVE CNTL ASSY	4
398724-1-1	VALVE SHUT OFF 3 INCH	2
400019000-001	VALVE BYPASS MANUAL	2
4060T64P04	SENSOR	1
4065-1	VALVE SOLENOID 3 WAY	1
4096T96P03	LEAD INGITION R/H	1
4159T91P03	HOSE ACTUATOR HEAD	2
444-2435-2	ACTUATOR ASSY, CABIN DOOR	3
449-2	POWER SUPPLY	2
453-0150	ELT	2
4622	VALVE HYD RELIEF	2
465630-02	PANEL, DUAL MSU	2
472597-02	CONTROL ALARM FIRE DETECTOR	3
4761040-503	DOOR ASSY LIFE VEST POUCH	1
49-164-05	CONTROL UNIT SPOILER	2
494600-0001	POWER SUPPLY	7
494600-0010	PWR SPLY - TAPE DECK	6
494601-0004	TAPE REPRODUCER	7
494601-0010	TAPE REPRODUCER	7
500-444	OVEN	4
5010520-1	BRAKE ASSY	3
5010598	NOSE WHEEL ASSY	36
5010-710-00-11	MONITOR BRAKE TEMP	4
501-1567-10	INDICATOR ATTITUDE	3
5071T98P02	AMPLIFIER, CONTROL	1
5182-1	AMP PASSENGER ADDRESS	1
5361-1-3	AUDIO CONTROL PANEL	4
5483-1-9	INTERPHONE HANDSET	11
54C54677E01	MANIFOLD GRD SPOILER	1
55E61-1	PRE-COOLER	2
5900778-21	DUCT, RAM AIR	1
600-10273-9	BUTE DOOR ASSY	1
600-10387-75	TRAILING EDGE ASSY WING BOX EXT LH	2



Part Number	Description	Quantity Available
600-10388-43	LH INBD FAIRING	2
600-10602-73	SPOILER ASSY FLIGHT	1
600-15109-34	REPLACED BY 600-15109-34S1	1
600-21134-43	VISOR ASSY, LOWER	3
600-21134-44	VISOR ASSY	1
600-31946-9	HANDLE	3
600-33039-3	ACCESS DOOR	2
600-33039-4	DOOR ACCESS ELECT BAY	3
600-33040-1	DOOR LOWER ELEC BAY	1
600-75122-7	EXCHANGER HEAT	1
601-10391-1S1	GLAZING ASSY	3
601-35009-21	DOOR ASSY	1
601-37003-159	DOOR UPPER FIREWALL	1
601-37003-160	PANEL LOWER FWD R/H	1
601-37003-161	DOOR LOWE FIREWALL	1
601-37003-162	DOOR FIREWALL LOWER R/H	1
601-37013-1	TRAILING EDGE PYLON LH	1
601-37014-17	THRUST MOUNT	2
601-37015-1001	YOKE FITTING ASSY L/H ENG MOUNT	5
601-37020-7	SHAFT	2
601-37040-13	BOLT ASSY FWD MOUNT	2
601-50910-13	CONDITIONER, ENGINE VIBRATION SIGNAL	1
601-50910-17	CABLE ASSY,VIB MONITORING ENGINE	1
601-80031-3	PICCOLO TUBE	2
601-80032-5	PICCOLO TUBE	2
601-80032-6	PICCOLO TUBE	2
601-80033-4	DUCT ASSY	1
601-97077-5	VALVE - COWL ANTI-ICE	1
601R10394-4	BUTE WING DOOR ASSY	1
601R12044-6	LEADING EDGE	1
601R12109-6R	GLASS	3
601R13000-2	AILERON	1
601R13040-23	BAR	2
601R13040-26	BAR	2
601R14002-2	FLAP INBOARD	1
601R14501-2	FLAP ASSY O/B	1
601R14571-7	LEADING EDGE FLAP VANE	2
601R21157-1	PANEL DOOR	1
601R21157-5	PANEL	2
601R28-059K1A	FUEL HARNESS SEGREGATION STRUCTURE INSTAL	1
601R31039-162	BIN ASSY, WHEEL	1
601R31051	EMEG EXIT L/H	1
601R31902-217	DOOR ACCESS	1
601R34-147K1	PITOT STATIC DRAIN	5



Part Number	Description	Quantity Available
601R380742-3	FITTING	3
601R38304-309	ACCESS PANEL	1
601R40154-4	PANEL, FILLER PSU	1
601R43127-1	DRAIN VALVE	1
601R43145-5	PUMP SUPPORT	1
601R49-015K1	APU OIL COOLING-EXHAUST REWORK CONFIG	1
601R49-015K2	APU OIL COOLING-APU ENCLOSURE REWORK	2
601R51075-45	PANEL, LIGHTING	1
601R51086-23	PANEL	3
601R51086-27	PANEL, A/C CONTROL	2
601R51162-27	BLEED AIR CONTROL PANEL	1
601R51164-5	PANEL CONTROL	3
601R51204-11	PANEL CONTROL	2
601R51226-23	PANEL CONTROL	5
601R51300-5/04	ENGINE CONTROL PANEL	2
601R51413-3	FIRE CONTROL PANEL	1
601R51518-5	PANEL ASSY WIPER/STALL	1
601R51555-3/01	CONTROL PANEL	2
601R51561-1	CONTROL ASSY, COMPASS	3
601R51572-3/A01	CONTROL PANEL	1
601R51577-1	AIR BOX ASSY	2
601R51586-7	PANEL ASSY DISPLAY REV SWITCH	3
601R51594-1	YAW DAMPER PANEL	1
601R51596-1	YAW DAMPER PANEL	1
601R51626-1	PANEL	1
601R51626-1/C01	CONTROL PANEL	1
601R51636-3	PANEL ASSY SPOILER /THRUST REV	1
601R51638-3	PANEL ASSY, AVIONIC COOL	1
601R51706-3	PANEL ASSY, STAB/MACH TRIM	1
601R51706-3/01	PANEL, STAB, MACH TRIM	2
601R51719-3	"MECH CALL" PANEL ASSY	7
601R51732-1	PANEL ENGINE SERVICE	3
601R53052-3	CONTROL OIL LEVEL	4
601R57900-19PE	HARNESS	1
601R57900-5	HARNESS ASSY	1
601R59025-7	POTENTIOMETER POSITION SENSOR	1
601R62401-19	TUBE ASSEMBLY.	1
601R75148-1	TRANSDUCER PRESSURE	2
601R87000-1	TRANSDUCER	1
601R93030-1	FLAP POSITION TRANSMITTER	4
601R93030-3	FLAP TRANSMITTER	2
601R95055-3	DUCT HYD HEAT EXCHANGER	1
601R95216-2	DUCT ASSY LOWER R/H (PRE SB 21-053)	2
601R95621-1	MANIFOLD ASSY.	1



Part Number	Description	Quantity Available
601R96062-1	COLLECTOR RING ASSY	1
601R97103-11	BELLOWS ASSY	3
601R97204-19	SHIELD ASSY APU EXHAUST	6
601R97209-13	SUPPORT ASSY DUCT	1
601R97608-27	SHAFT (LH)	1
60730-000-1	TRANSDUCER MACH	4
6190-1	FUSE HYD / BYPASS	4
622-5812-006	FLUX VALVE	1
622-7382-101	RECEIVER ADF-462 ADF	3
622-8971-022	COMPUTER TCAS	4
622-9810-010	ELEC FLT DISP W/EICA	2
622-9814-005	CONCENTRATOR	1
622-9815-604	FLIGHT CONTROL COMPUTER FCC-4000	1
622-9815-904	FLIGHT CONTROL COMPUTER - FCC 400	5
622-9820-004	DATA CONCENTRATOR UNIT	1
622-9851-001	COMM/NAV TUNING UNIT	2
622-9852-106	RADIO TUNER UNIT	2
622-9945-003	POWER SUPPLY	7
6233M30A	ACELRMTR, ENGINE VIBRATION	3
700-1010-1	FLOOR PANEL ASSY	1
7060-10	HORIZONTAL STABILIZER CONTROL	2
70628-14464-103	PICCOLO TUBE	1
70628-14464-104	PICCOLO TUBE	2
720845E	AC GENERATOR	1
720846D	GENERATOR CONTROL UNIT	4
720847A	TRANSFORMER	1
721863C	UPLOCK ASSY	2
722514	FUEL LEVEL SENSOR	1
728431B	EJECTION JACK & HOSE OUTLINE	2
7302-1	RESERVOIR HYD	3
731879C	ADG HAND PUMP	1
736643-10	COMPUTER FUEL 3	2
7-44911-31	PUSHPULL ASSY, FWD LH / RH	5
7-45319-3	CONTROL UNIT - GALLEY WATER SYSTEM	2
750004000-003	VALVE BYPASS	3
750005000	VALVE SELECTOR MLG	2
750659-16	SWITCH OVER TEMP	1
750659-17	SWITCH O/T	1
750662-8	VALVE SEPRATOR ASSY	5
750665-9	SWITCH O/T	4
753355-4	HEAT EXCHANGER	4
753355-9	HEAT EXCHANGER	4
756654A	CONTROL UNIT GENERATOR	2
768094-1	FUEL QTY TRANSMITTER	3



Part Number	Description	Quantity Available
768271-2	FUEL QTY TRANSMITTER	2
768272-3	FUEL QTY TRANSMITTER	3
768273-2	FUEL QTY TRANSMITTER	1
768274-3	FUEL QTY TRANSMITTER	2
768284-2	FUEL QTY TRANSMITTER	1
768656-1	FUEL QTY TRANSMITTER	2
768657-1	FUEL QTY TRANSMITTER	2
785-806-2	CONTROLLER AIR DATA	4
798-114-4A	DFG	1
7G989	SWITCH PRESSURE HYD	8
806224-1	FAN HOUSING	1
808440-2	VALVE ASSY DUAL BYPASS	4
816101-2	CONTROLLER TEMP	1
818818-2	TUBE, WATER SEPARATOR	1
82046-4	CONTROL, ADG AUTO DEPLOY	1
82046-5	CONTROL ADG AUTO DEPLOYMENT	2
822-0044-001	FLIGHT CTRL PANEL	2
822-0049-001	CONFIGURATON STRAPPING UNIT	1
822-0198-001	CARD CAGE	2
822-0260-001	MOUNT SERVO SMT-87B	3
822-0332-401	LIGHTNING PROTECTOR	2
822-0393-001	RECEIVER VHF NAV - VIR 432	2
848526	STATOR HOUSING ASSEMBLY	1
848847	HYDRAULIC PUMP	2
852D100-23	ACTUATOR FLAP	2
852D100-25	ACTUATOR FLAP INBD	6
855D100-9	BRAKE POSITION SENSOR UNIT	3
897889-2	APU CONTAINER:FIRE EXT	1
899074-1	EXTINGUISHER, FIRE CONTAINER	5
899486-1	ENG FIRE BOTTLE	1
8ES005421-09	POWER SUPPLY	4
8TJ118AAC	FAN SPEED SENSOR	1
9011350100-1	DAMPENER PULSATION	1
9048120-3	LEAD, CF34 IGNITION RH	3
9048120-4	LEAD, CF34 IGNITION LH	6
93-A151-20	CVR CONTROL UNIT	2
9700-C1A-BF23A	OXYGEN PORTABLE UNIT	3
9700-C1A-BF23B	OXYGEN PORTABLE UNIT	4
970500-7	REGULATOR, TENSION (LH)	1
979626-3-1	VALVE S/O	1
9FT407998-00	LIGHT ASSY	2
A1815A7	LIGHT ASSY NAV	1
AD-A686-30	MANIFOLD PRESSURE	4
AE0607AA2	FAN ASSY - ARINC 600	3



Part Number	Description	Quantity Available
AE1410CA1	FAN, AVIONIC EXHAUST	2
AE709007-2	HYD LINE	2
AE709034-3	HOSE ASSY	4
AE709040-2	LINE HYD	1
AE709041-2	LINE HYD	2
AL00102	ACTUATOR	5
B97-13-653	VALVE APU SHUT OFF	1
B97-31-655	VALVE, ENGINE SHUT-OFF	3
BA23217-1	LAV FIRE BOTTLE	1
BF5-0353-901	HOUSING ASSY	2
D18ZZA	CONTACTOR	1
D-18ZZC	CONTACTOR	5
D-7GRZ	RELAY	3
D97C00-637	ACTUATOR, FUEL FEED	1
DL2428M4	ACTUATOR LINEAR	3
DMN4-17-1/N	ANTENNA	7
DMN4-17-1N08	ANTENNA VOR/ILS RH	3
ELP-362D	ULB	1
F3613007200000	DUCT ASSY	1
FE210-006	QUADRANT ENGINE THROTTLE	1
FE210-008	QUADRANT ENGINE THROTTLE	1
FE210-302	CAM SWITCH UNIT, THROTTLE POSITION	1
G601R101216-1	ENGINE BY PASS COVERS	1
GMT4190-020	CLOCK DIGITAL PILOT	1
GP15-38-1	GAUGE PRESS INDICATOR	3
H2992-3	LATCH ASSY LOWER COWL	3
H3414-39	HANDLE ASSY - PAX DOOR	1
J243E0104-135BA	HOSE ASSY	1
J243F0165-350CA	HOSE ASSY	3
MODEL1158	HOT JUG (LIQUID CONTAINER 6,7 L)	6
MR-10037N	PERSONAL BREATHING EQUIPMENT PBE	1
MS17976-2	TRU CONVERTER	1
MXP411	BOX, STOWAGE (RH)	2
P194-395	VALVE SELECTOR OIL	2
P44-771	VALVE RELIEF	1
PA1-700	VERTICAL CARD MAGNETIC COMPASS	2
RCF67-06	REGULATOR PRESSURE	2
S41422-2	ANTENNA, GLIDESLOPE	2
S7209	INSTR. CURRENT TRANSFORMER	1
ST314-2R	PORT STATIC PRESSUR R/H	1
VP0615E00	VALVE S/O	5
VP1257C00	VALVE EXHAUST	2
X8905	MANIFOLD, MAINFEED	1